

Calculation of the number of reinforcements – parameters

#	Impact energy	Number of stiffeners for higher frames [N1]	Number of stiffeners for wider frames [N2]	Total number per post [N]
1	E = 176 J	N1 = ABRUNDEN(H/2300;0)	N2 = ABRUNDEN(L/2000;0)	N = N1 + N2
2	E = 370 J	N1 = ABRUNDEN(H/2300;0)	N2 = ABRUNDEN(L/2000;0)	N = N1 + N2
3	E = 882 J	N1 = ABRUNDEN(H/2300;0)	N2 = ABRUNDEN(L/2000;0)	N = N1 + N2